## 排水渠管維修

What you need to know about drainage pipe maintenance





屋宇署 Buildings Department 2021年3月 March 2021

## 住宅單位排水渠管 及衛生設備檢查維修指引

應定期檢查所有室內排水渠管和相連的衞生設備,並特別留意圖中以 紅色虛線顯示部分。

All internal drainage pipes and associated sanitary fitments should be inspected regularly, with special attention being paid to the parts marked with red dotted lines in the following photos.

如發現下列現象,應立即通知大廈管理處或安排合資格的建築專業 人士/承建商進行檢查/維修。

If any of the following phenomena arises, please report immediately to your building management office or arrange a qualified building professional / contractor for inspection / repair.

> 排水渠管/衞生設備發出異味或異響 foul smell or odd sound from drainage pipes /

> 排水渠管/衞生設備出現裂縫或銹水漬

排水渠管/衞牛設備滲漏或淤塞 sanitary fitments

水廁內不時泛起氣泡 bubbles coming out of the water closet from time to time



切勿將雜物丟進水廁及去水口內, 以免造成排水渠管淤塞。

Do not drop any objects into the water closets and the drainage outlets to avoid blockage of the drainage pipes.


每星期用約半公升清水倒進 每個地台去水口。如找不到 地台去水口,請向大廈管理處 或合資格的建築專業人士/ 承建商杳詢。

Pour about half a litre of water into each floor drain every week. If you cannot find the floor drains. please contact your building management office or consult a qualified building professional / contractor.



不應在浴室安裝馬力過強的抽氣扇,如有疑問,請諮詢 合資格的建築專業人士/承建商。

Do not install exhaust fans of excessive capacity in bathrooms. For enquiries, please contact a qualified building professional /



確保所有衞牛設備有滴當的隔氣變管。

企缸

个缸沒有安裝隔氣彎管\*,直接接駁排水渠管 A shower tray without a trap\* is directly

connected to the drainage pipe.

Δ

滴當的隔氣變管

suitable trap

\*隔氣彎管應有反虹吸管通風,或以建造方式防止水封流失。

排水渠管 drainage pipe

A trap should be ventilated by an anti-syphonage pipe or constructed to prevent loss of water seal.

water seal

排水渠管

drainage pipe



排水渠管 drainage pipe







洗衣機去水口應設有適當的 隔氣彎管並接駁至廢水管。

> Washing machine drainage outlet should be provided with a suitable trap and connected to a waste pipe.



8

為防止水封流失,如有多於一個屬廢水/污水設備的隔氣彎管接駁至一條廢水/污水渠管,該隔氣彎管須以反 虹吸管通風,但廢水設備的隔氣彎管亦可以反虹吸氣閥 防止水封流失。

To prevent loss of water seal, if more than one trap of a waste / soil fitment is connected with one waste / soil pipe, the traps should be ventilated by means of anti-syphonage pipes, whereas the traps to waste fitments can be embodied with anti-syphonage air valves to prevent loss of water seal.

確保隔氣彎管正常運作,切勿拆除或改動反虹吸管或備有反虹吸氣閥 的隔氣彎管,亦不應以沒有反虹吸作用的隔氣彎管更換原有有反虹吸 作用的隔氣彎管。

Make sure that all traps are functioning properly. Do not remove or alter the anti-syphonage pipes or the traps with anti-syphonage air valves of the waste / soil

fitments, and do not replace a trap with anti-syphonage function by a trap without such function.



反虹吸管 Anti-syphonage pipe



10

依從衞生署發出的指引,進行日常家居清潔及消毒工作,以及 保持個人衞生。

Observe the guidelines issued by the Department of Health to clean and disinfect your flat and maintain good personal hygiene.



## 如有查詢<sup>,</sup>請致電 屋宇署熱線2626 1616

(由「1823」代為接聽)

For enquiries, please call Buildings Department's Hotline 2626 1616

(Handled by "1823")



屋字署網站 Buildings Department Website www.bd.gov.hk



防疫資訊 渠管健康 https://bit.ly/3arSvxl



Epidemic Prevention Information Healthy Drains https://bit.ly/3r9TV5Z