

Proper use

Regular cleaning

- Windows are subject to wear and tear and exposed to weather, thus requiring regular cleaning.
- Clear the bar hinges, sliding shoes and tracks of dust, dirt and debris frequently.
- Use water for cleaning purpose. Do not use acidic or alkaline cleaning agents. Wipe off any water left on the top of one window sash and the bottom of the frame.



Periodic lubrication

- Lubricate lightly the movable parts of the window such as hinges, tracks and pivoting points to avoid undesired friction and undue wear and tear of the rivets/screws when opening the windows.



No overloading



- Do not hang any objects on the window sash to avoid causing additional load on the bar hinges.

- Do not impose pressure on the window sash such as by transferring the body weight onto the sash when cleaning windows. Such extra loading, which has not been designed for, will over-stress the windows, in particular, the weakest link at the bar hinges.



No forced opening and closing

- Do not push or pull the window sash with excessive force when the windows are hard to operate. Otherwise, this will induce excessive stress on the pivots, rivets and screws, causing their loosening or detachment.

